

### 1. Product and Storage Information

**Product Description:** A UV Curable Clear Heavy Bodied Sanding Surfacer that is applied by spray, roll, and brush. For use on substrates such as woods, synthetics, metals, and plastics. Can be applied over pre-finished fully cured substrates.

Excellent adhesion, sealing and rigidity. No shrink. Non-yellowing. Easy sand, good hold out. Brush, roll, blade, spray. High build. Single component.

#### Suitable Surfaces:

2K Surfacer	Epoxy Primer
Stone	Lexan
Tintable Sealer	Corian
Veneer / Hardwood	Carbon Fiber / FRP
Wood, Metal, and Plastics	Base Coat

**Storage:** The product should be stored within the temperature range of 50°f to 90°f and in the original container. Do not return unused material into the original bottle.

## 2. Application



Use suitable respiratory and PPE equipment

See Section 6 (Liability/Hazard Info) for more details

Clean Armor Technology, LLC 7222 Commerce Center Drive, Suite 220 Colorado Springs, CO 80919



# Technical Data Sheet BluSky Armor® 1088 HB Surfacer



**Preparation Process:** Use 90-99% isopropyl alcohol (IPA) to prep before application of the coating.

You may use a wax and grease remover or tack cloth, to prepare the surface to be coated, but it must be followed up with a 90-99% isopropyl alcohol (IPA) prep prior to application of the coating.

**Application Process: Shake or Stir well before use.** Apply in a well-ventilated area, use appropriate PPE and a respirator (full / half mask) for spray coating (refer to SDS). Hand apply, brush, roll, or spray onto substrate. Product can be applied at temperature ranges of between 60°f and 112°f as well as humidity between 20% and 97%. Product temperature should be at minimum 72°F. Depending on spray equipment, product may need to be reduced no more than 20% to spray viscosity with 90-99% isopropyl alcohol, Substrate temperature should be at minimum 60°f. Any spray equipment may be used. The recommended tip size is 1.0 - 1.6 mm. Follow standard shop practice when spraying. The remaining unused polymer should be stored in an opaque container and may be reused as long as the viscosity has not increased. Unused polymer should not be returned to the original container. The spray equipment can be cleaned with isopropyl alcohol or acetone.

# WARNING: material will start curing immediately when applied in direct or indirect sunlight.



#### **Build Coats**

#### For Open Grain Finish:

1. Hand apply material with a lint free applicator.

2. Remove all excess material and then cure.

3. Allow 5 minute post cure before the next coat.

4. Lightly scuff surface with 320 grit or higher paper. Remove any debris.

Second coat can be applied to the desired look using hand or spray application.



#### For Closed Grain Finish:

For large porous or deep grain veneers on vertical or horizontal surfaces.

- 1. Hand apply with a lint free applicator or roller. Allow to dwell for 2 minutes.
- 2. Squeegee off all excess material and then cure.
- 3. Allow 5 minute post cure before the next coat.
- 4. Degloss with 320 grit or finer paper. Remove any debris.
- 5. For remaining coats apply using the Standard Finish steps to desired finish spec.

#### For Standard Finish:

- 1. Apply 1 to 3 mils per application.
- \*Note: For vertical applications recommended coverage 1-1.5 mil.
- 2. Allow flow out to desired profile.
- 3. Cure for 2-4 min with UVA curing light or direct sunlight.
- 4. Allow 5 minute post cure before the next coat.

For additional coats sand with 220 grit or finer paper between coats. Use shop air and prep with IPA.

#### Repeat steps 1-4 for additional coats.

NOTE: Not recommended to exceed 4 mils above existing surface, pre-existing finish, or grain filled wood. Sealer is designed to be very rigid to improve holdout for top coats and is not designed to be polished.

#### Spray Gun Set-Up / Application Pressure:

RP - Gravity Feed	1.0 - 2.0 mm	29 -35 psi
HVLP - Gravity Feed	1.0 - 2.0 mm	Max 20 psi (cap)



# 3. UV Through Cure Verification

Use this procedure to verify your UVA light is adequate to thoroughly cure the product.



1. Use a test article and apply a 3 mil coat.

2. Cure with UV light 2 minutes.

3. Let rest for 10 minutes.

4. Check for a tack free surface. If it's not tack free then it has insufficiently cured\*.

5. Take 220 grit sandpaper and sand completely through looking for dry powder all the way through. If you encounter gummy material or clogged sandpaper then it has insufficiently cured\*.

\*An insufficient cure indicates that the UVA light is unable to cure the product. (This could be due to the distance or total output power of the light)

## 4. Cleaning Process

Use isopropyl alcohol and/or acetone to clean tools and equipment. Cure excess or unwanted material on surfaces or filters with UV light.

## 5. Material Details

Solid Content	100%
Volatile Organic Content	0%
Coverage @ 1 mil	1608 sq. ft./gal



## 6. Liability/Hazard Info

See SDS for complete information.

Although the product is VOC free it should be used in a well-ventilated area.

If skin contact occurs immediately wash with soap and water.

Harmful if swallowed.

Causes skin and eye irritation and may cause an allergic skin reaction.

WARNING: Exposing open containers or barrels of product to direct or indirect sunlight will result in a run away exothermic reaction. Product is unstable until properly cured.

Standard Disclaimer: EXCEPT AS SPECIFIED ABOVE OR PROHIBITED BY APPLICABLE LAW. ALL EXPRESS OR IMPLIED CONDITIONS AND WARRANTIES, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR ACCURACY OF ANY INFORMATIONAL CONTENT, ARE HERE BY EXCLUDED AND DISCLAIMED BY CLEAN ARMOR TECHNOLOGY, LLC; AND IN NO EVENT WILL CLEAN ARMOR TECHNOLOGY, LLC BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES HOWSOEVER ARISING AND REGARDLESS OF THE THEORY OF LIABILITY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. PRODUCTS, PRICES, AVAILABILITY, SPECIFICATIONS, AND OFFERS ARE SUBJECT TO CHANGE OR CANCELLATION AT ANY TIME WITHOUT NOTICE.

Personal Protective Equipment: Eye/face protection: Face shield and safety glasses Use equipment for eye protection tested and approved under appropriate government standards such as NIOSH (US) or EN 166(EU).

Skin protection: Handle with gloves. Gloves must be inspected prior to use. Use proper glove removal technique (without touching gloves outer surface) to avoid skin contact with this product. Dispose of contaminated gloves after use in accordance with applicable laws and good laboratory practices. Wash and dry hands.

Body Protection: Use full paint suit with hood, The type of protective equipment must be selected according to the concentration and amount of the dangerous substance at the specific workplace.

Respiratory protection: Where risk assessment shows air-purifying respirators are appropriate use a full-face respirator with multi-purpose combination (US) or type ABEK (EN 14387) respirator cartridges as a backup



to engineering controls. If the respirator is the sole means of protection, use a full-face supplied air respirator. Use respirators and components tested and approved under appropriate government standards such as NIOSH (US) or CEN (EU).

Control of environmental exposure: Do not let product enter drains.